

REPLACEMENT PARTS FOR CATERPILLAR* DIESEL ENGINES

PART NO.*	DESCRIPTION*	UNIT PRICE
DP-105-2508	PUMP, PRIMING	16.54
DP-108-2102	BONNET	26.24
DP-108-2104	PLUNGER & BARREL 11 mm	65.78
DP-108-6630	PLUNGER & BARREL ASSY. 11 mm	198.98
DP-108-6631	PLUNGER & BARREL 11 mm	
DP-113-7794	BUSHING	16.18
DP-119-8699	WEIGHT	21.90
DP-142-2818	BARREL & PLUNGER	28.72
DP-1P1098	SERVICE GROUP	14.79
DP-1P2298	USE DP-7E5346	
DP-1P3409	PUMP, FUEL	89.28
DP-1P6400	BARREL & PLUNGER 10 mm	36.98
DP-1P7324	USE DP-3T9562	
DP-1S0214	SPRING	13.42
DP-1S5440	PIN	0.82
DP-1S7592	SPRING, FOR BARREL AND PLUNGER	3.62
DP-1S9410	USE DP-8M2667	
DP-1W3010	BARREL & PLUNGER	28.72
DP-1W5337	SHAFT ASSEMBLY	82.08
DP-1W5339	SHAFT ASSEMBLY	103.92
DP-1W5434	CARRIER	94.20
DP-1W5829	PENCIL NOZZLE	55.45
DP-1W6539	BARREL & PLUNGER ASSY.	148.75
DP-1W6541	BARREL & PLUNGER 9 mm	37.07
DP-1W6982	USE DP-4P7688	
DP-1W6987	CHECK VALVE	19.52
DP-1W6987-3	SPRING, FOR CHECK VALVE	1.40
DP-1W9171	BONNET	19.62
DP-2M4314	USE DP-7E5085	
DP-2N0477	WEIGHT	34.08
DP-2N0479	CARRIER ASSEMBLY	184.28
DP-2S0101	USE DP-2N0477	
DP-2S1631	CHECK VALVE	3.99
DP-2S4442	NOZZLE	14.38
DP-2S7264	PUMP, FUEL	89.28
DP-2S9828	NOZZLE	14.38
DP-2W2604	PRIMING PUMP	19.90
DP-2W2605	PRIMING PUMP	21.23
DP-2W3409	USE DP-108-2102	
DP-2W3413	USE DP-108-6630	
DP-2W3414	USE DP-108-6631	
DP-3N0972	SERVICE GROUP	14.79
DP-3N1299	NOZZLE	14.38
DP-3S1467	PUMP, FUEL	167.02
DP-3S6638	SERVICE GROUP	14.79
DP-3S8336	BARREL & PLUNGER	37.88
DP-3T8705	GLOW PLUG	12.35
DP-3T8706	GLOW PLUG	7.77
DP-3T9562	GLOW PLUG	7.99
DP-4M0411	BONNET	18.98
DP-4N0209	BONNET	18.98
DP-4N0218	USE DP-7W8120	
DP-4N0360	USE DP-3T8706	
DP-4N0406	GEAR IDLER 3208, 10 TEETH	12.88

PART NO.*	DESCRIPTION*	UNIT PRICE
DP-4N0425	WEIGHT	34.08
DP-4N0429	GEAR DRIVE 3208, 15 TEETH	13.77
DP-4N0446	USE DP-8N2663	
DP-4N0511	PIN	0.82
DP-4N1132	PUMP HOUSING BODY 3208, WITHOUT SEAL	61.75
DP-4N1132-2	PUMP HOUSING BODY 3208, WITH SEAL	65.55
DP-4N1251	NOZZLE	14.38
DP-4N1808	CARRIER ASSEMBLY	176.02
DP-4N2484	BONNET	14.77
DP-4N2728	RETAINER	1.52
DP-4N2773	TACH SHAFT 3208	34.34
DP-4N2954	DRIVE HUB	13.55
DP-4N4318	USE DP-9N5862	
DP-4N4320	SHAFT ASSEMBLY	40.66
DP-4N4997	BARREL & PLUNGER 10 mm	38.88
DP-4P2899	USE DP-113-7794	
DP-4P7688	CHECK VALVE	19.62
DP-4P7688-3	SPRING	1.29
DP-4P9830	PLUNGER AND BARREL ASSEMBLY 10.5 mm	65.77
DP-4S5758	BARREL & PLUNGER ASSEMBLY 7 mm	46.77
DP-4S7913	BARREL & PLUNGER	64.56
DP-4W0788	USE DP-105-2508	
DP-4W1819	PENCIL NOZZLE	98.77
DP-4W5869	USE DP-1W6987	
DP-4W7015	NOZZLE ASSEMBLY	81.22
DP-4W7016	NOZZLE ASSEMBLY	81.22
DP-4W7017	NOZZLE ASSEMBLY	78.88
DP-4W7018	NOZZLE ASSEMBLY	78.88
DP-4W7019	NOZZLE ASSEMBLY	78.88
DP-4W8483	PENCIL NOZZLE	78.88
DP-5B3718	O' RING	0.39
DP-5F2805	USE DP-9F2393	14.38
DP-5H5836	NOZZLE	14.38
DP-5H7936	SERVICE GROUP	14.79
DP-5M4086	NOZZLE	14.38
DP-5P4810	USE DP-7W6335	
DP-5P8062	FUEL PUMP GASKET KIT 3406	70.12
DP-5P8214	FUEL PUMP GASKET KIT 3406	71.16
DP-5P8329	FUEL PUMP GASKET KIT 3406	70.48
DP-5P8391	FUEL PUMP GASKET KIT 3406	70.16
DP-5P8982	FUEL PUMP GASKET KIT D353	102.74
DP-5P9148	FUEL PUMP GASKET KIT 3406	52.42
DP-5P9216	FUEL PUMP GASKET KIT 3208	31.88
DP-5P9338	FUEL PUMP GASKET KIT 1674	67.74
DP-5P9339	FUEL PUMP GASKET KIT D334	78.72
DP-5P9390	FUEL PUMP GASKET KIT 1140, 1145	36.50
DP-5P9397	FUEL PUMP GASKET KIT 3160	26.60
DP-5P9419	FUEL PUMP GASKET KIT D4	28.50
DP-5P9461	FUEL PUMP GASKET KIT 3304, 3306	32.66
DP-5P9556	FUEL PUMP GASKET KIT D342	57.98
DP-5P9581	FUEL PUMP GASKET KIT 1673	75.62
DP-5P9833	FUEL PUMP GASKET KIT D8	55.34
DP-5P9835	FUEL PUMP GASKET KIT D8	64.24
DP-5P9859	FUEL PUMP GASKET KIT 3408	98.54
DP-5P9948	FUEL PUMP GASKET KIT 910	16.78
DP-5S5058	GEAR 66 TEETH	54.74

PART NO.*	DESCRIPTION*	UNIT PRICE
DP-5S5060	USE DP-2N0479	
DP-6F1069	SEAL RING	1.28
DP-6H3364	SERVICE GROUP	14.79
DP-6I1327	BONNET	19.62
DP-6N0024	SPRING	1.36
DP-6N0248	SHAFT ASSEMBLY	49.99
DP-6N1043	PUMP, FUEL	119.00
DP-6N1133	FUEL PUMP GASKET 3306	23.20
DP-6N1311	CARRIER FOR WEIGHT 6N1312	184.28
DP-6N1312	WEIGHT	36.16
DP-6N2766	BARREL & PLUNGER	49.99
DP-6N2767	PUMP, FUEL	167.77
DP-6N3723	FUEL PUMP GASKET 3208	23.85
DP-6N7527	BARREL & PLUNGER 8 mm	24.09
DP-6N7828	USE DP-7W0182	
DP-6V0241	FUEL PUMP GASKET KIT 3408	75.50
DP-6V0623	FUEL PUMP GASKET KIT 3304, 3306	69.32
DP-6V0908	FUEL PUMP GASKET KIT D333	57.08
DP-6V1667	FUEL PUMP GASKET KIT D353	160.46
DP-6V1692	FUEL PUMP GASKET KIT D353	81.08
DP-6V1848	FUEL PUMP GASKET KIT 3406	61.40
DP-6V1980	FUEL PUMP GASKET KIT 3306	49.24
DP-6V1981	FUEL PUMP GASKET KIT 3306	80.98
DP-6V2245	FUEL PUMP GASKET KIT D4	42.66
DP-6V2251	FUEL PUMP GASKET KIT 3304, 3306	41.76
DP-6V2354	FUEL PUMP GASKET KIT 3306	84.42
DP-6V2414	FUEL PUMP GASKET KIT D5, D6, D7	49.10
DP-6V2547	FUEL PUMP GASKET KIT 3412	68.12
DP-6V2901	FUEL PUMP GASKET KIT 3304, 3306	44.64
DP-6V2909	FUEL PUMP GASKET KIT 3208	35.28
DP-6V2941	FUEL PUMP GASKET KIT D353	117.66
DP-6V2959	FUEL PUMP GASKET KIT D353	132.86
DP-6V2960	FUEL PUMP GASKET KIT D353	139.58
DP-6V2972	FUEL PUMP GASKET KIT D5, D6, D7	38.22
DP-6V3726	FUEL PUMP GASKET KIT D349	159.84
DP-6V3729	FUEL PUMP GASKET KIT D4, D5	35.86
DP-6V3742	FUEL PUMP GASKET KIT D379, D398	63.78
DP-6V4573	FUEL PUMP GASKET KIT D349	185.82
DP-6V4574	FUEL PUMP GASKET KIT D349	216.38
DP-6V4707	FUEL PUMP GASKET KIT 3306	31.44
DP-6V4720	FUEL PUMP GASKET KIT 953	36.36
DP-6V4756	FUEL PUMP GASKET KIT D342	73.16
DP-6V4770	FUEL PUMP GASKET KIT D342, 3306B	50.38
DP-6V4780	FUEL PUMP GASKET KIT 3304	30.78
DP-6V4788	FUEL PUMP GASKET KIT 3306	37.06
DP-6V5425	FUEL PUMP GASKET KIT G379	309.18
DP-6V5455	FUEL PUMP GASKET KIT D379, 3398	256.02
DP-6V5459	FUEL PUMP GASKET KIT D379, D398	152.44
DP-6V5467	FUEL PUMP GASKET KIT D379, D398	141.04
DP-6V5494	FUEL PUMP GASKET KIT D379	110.20
DP-6V5497	FUEL PUMP GASKET KIT 3406	72.82
DP-6V6367	FUEL PUMP GASKET KIT 1693	138.48
DP-6V6368	FUEL PUMP GASKET KIT 1693	145.34
DP-6V6369	FUEL PUMP GASKET KIT 1693	159.16
DP-6V7429	FUEL PUMP GASKET KIT D398	136.30
DP-6V7461	FUEL PUMP GASKET KIT 3304	34.72

PART NO.*	DESCRIPTION*	UNIT PRICE
DP-6V8028	FUEL PUMP GASKET KIT 637D	51.00
DP-6V8042	FUEL PUMP GASKET KIT 140G, 3306	34.72
DP-6V8575	FUEL PUMP GASKET KIT 1676, D336	123.22
DP-6V8908	FUEL PUMP GASKET KIT 936	24.26
DP-6V9223	FUEL PUMP GASKET KIT 3406B, 825C	80.54
DP-6V9245	FUEL PUMP GASKET KIT 3406	64.56
DP-6V9701	FUEL PUMP GASKET KIT D399	154.18
DP-6V9710	FUEL PUMP GASKET KIT D399	144.50
DP-6V9711	FUEL PUMP GASKET KIT D399	140.38
DP-6V9715	FUEL PUMP GASKET KIT 3406	56.50
DP-6V9725	FUEL PUMP GASKET KIT 3406B	62.34
DP-6V9882	FUEL PUMP GASKET KIT 3204	54.50
DP-6V9894	FUEL PUMP GASKET KIT 3406B	63.16
DP-6V9908	FUEL PUMP GASKET KIT 312G, 3306B	47.92
DP-7C6617	BUSHING	14.99
DP-7E3969	NOZZLE PENCIL	70.41
DP-7E3986	CARRIER	55.04
DP-7E5085	BUSHING	9.72
DP-7E5346	INSERT	1.25
DP-7E6006	USE DP-108-6633	
DP-7E6007	USE DP-108-2104	
DP-7M4190	NOZZLE	14.38
DP-7M4601	NOZZLE	14.38
DP-7M7431	SERVICE GROUP	14.79
DP-7N0449	PENCIL NOZZLE	57.44
DP-7N1067	SPRING	3.62
DP-7N1183	BARREL & PLUNGER 10.5 mm	39.88
DP-7N1185	BARREL & PLUNGER 10 mm	145.45
DP-7N1208	SPRING	3.68
DP-7N1219	PUMP, FUEL	149.99
DP-7N1220	BARREL & PLUNGER 10 mm	39.99
DP-7N1415	WASHER, FOR BARREL AND PLUNGER	1.12
DP-7N5005	USE DP-8N1831	
DP-7N7264	WEIGHT	23.56
DP-7N9843	NOZZLE	14.38
DP-7S1059	USE DP-8N1831	
DP-7S5105	NOZZLE	14.36
DP-7S6681	BARREL & PLUNGER 9 mm	39.98
DP-7S8722	NOZZLE	14.38
DP-7S9891	SERVICE GROUP	14.79
DP-7W0182	BARREL & PLUNGER 10 mm	36.98
DP-7W2808	WASHER-RETAINER	1.55
DP-7W3710	PENCIL NOZZLE	94.88
DP-7W5928	BARREL & PLUNGER	94.88
DP-7W5929	BARREL & PLUNGER	38.98
DP-7W6335	CAMSHAFT BUSHING 3208	4.33
DP-7W7026	NOZZLE ASSEMBLY	84.99
DP-7W7030	NOZZLE ASSEMBLY	84.99
DP-7W7032	NOZZLE ASSEMBLY	84.99
DP-7W7037	NOZZLE ASSEMBLY	84.99
DP-7W8039	BONNET	18.38
DP-7W8120	BUSHING	
DP-7W8120	BUSHING	7.65
DP-7X0852	FUEL PUMP GASKET KIT 3406B	71.36
DP-7X2633	FUEL PUMP GASKET KIT 3406B	146.38
DP-7X2754	FUEL PUMP GASKET KIT 3406B	142.34

PART NO.*	DESCRIPTION*	UNIT PRICE
DP-7X7969	FUEL PUMP GASKET KIT 245B, 3406B	66.46
DP-7X7971	FUEL PUMP GASKET KIT 3176	46.74
DP-8C4452	FUEL PUMP GASKET KIT 3406	96.10
DP-8C5790	FUEL PUMP GASKET KIT 3306,3306B	54.88
DP-8C6538	FUEL PUMP GASKET KIT 3406B	69.14
DP-8C6772	FUEL PUMP GASKET KIT 3406B	62.10
DP-8C8490	FUEL PUMP GASKET KIT 3406B	48.80
DP-8C8764	FUEL PUMP GASKET KIT 3406B	74.68
DP-8L8883	SHAFT	43.70
DP-8M1584	SERVICE GROUP	14.79
DP-8M2667	PUMP, FUEL	89.99
DP-8M2701	USE DP-2S7264	0.00
DP-8M2899	USE DP-1P3409	0.00
DP-8M3279	PUMP, FUEL	89.99
DP-8M3280	PUMP, FUEL	89.99
DP-8M9753	PUMP, FUEL	89.99
DP-8M9754	PUMP, FUEL	89.99
DP-8M9755	PUMP, FUEL	89.99
DP-8M9757	PUMP, FUEL	89.99
DP-8M9758	PUMP, FUEL	89.99
DP-8M9760	PUMP, FUEL	89.99
DP-8M9761	PUMP, FUEL	89.99
DP-8N0656	USE DP-7C6617	
DP-8N1414	CHECK VALVE	28.52
DP-8N1414-3	SPRING FLOW CHECK	1.20
DP-8N1415	CHECK VALVE	1.40
DP-8N1417	BONNET	18.38
DP-8N1831	NOZZLE	14.38
DP-8N2478	USE DP-7N9843	
DP-8N2510	SHAFT	16.98
DP-8N2511	CARRIER	50.62
DP-8N2516	BONNET	18.38
DP-8N2663	CARRIER	40.90
DP-8N3088	SHAFT ASSEMBLY	60.94
DP-8N3173	NOZZLE	14.38
DP-8N3174	NOZZLE	14.38
DP-8N3175	NOZZLE	14.38
DP-8N3176	NOZZLE	14.38
DP-8N3177	NOZZLE	14.38
DP-8N3178	USE DP-6H3364	
DP-8N3539	BARREL & PLUNGER 9 mm	39.77
DP-8N3945	BUSHING 3208	5.76
DP-8N3946	GOV. HOUSING 3208	159.98
DP-8N4694	NOZZLE	14.38
DP-8N4697	NOZZLE	14.38
DP-8N5117	BUSHING	11.78
DP-8N5403	SHAFT ASSEMBLY	69.99
DP-8N5986	USE DP-3S6638	
DP-8N5993	SPRING FLOW CHECK	2.20
DP-8N7005	NOZZLE ASSEMBLY	69.99
DP-8N8796	SERVICE GROUP	14.79
DP-8S3656	BARREL & PLUNGER 10 mm	39.99
DP-8T1615	FUEL PUMP GASKET KIT D348	106.96
DP-8T1624	FUEL PUMP GASKET KIT 3306	50.42
DP-8T1635	FUEL PUMP GASKET KIT 3208	44.26
DP-8T1636	FUEL PUMP GASKET KIT 3406	114.90

PART NO.*	DESCRIPTION*	UNIT PRICE
DP-8T1653	FUEL PUMP GASKET KIT 3306B	39.40
DP-8T2470	FUEL PUMP GASKET KIT 3204	57.34
DP-8T6692	FUEL PUMP GASKET KIT 9103406B	81.98
DP-8T6734	FUEL PUMP GASKET KIT 931, D3, D4	45.32
DP-8T7539	FUEL PUMP GASKET KIT 3306B	31.36
DP-8T7562	FUEL PUMP GASKET KIT 3306B	59.30
DP-8T9081	FUEL PUMP GASKET KIT 3406B	74.60
DP-9B1320	CHECK VALVE	3.81
DP-9B1363	SPRING	0.77
DP-9F2393	SERVICE GROUP	14.79
DP-9F4113	NOZZLE	14.38
DP-9H2256	PUMP, PRIMING	22.11
DP-9H5746	CHECK VALVE	3.72
DP-9H5796	BARREL & PLUNGER 8 mm	36.98
DP-9H5797	BARREL & PLUNGER 8.5 mm	33.20
DP-9L4102	BARREL & PLUNGER 9 mm	44.32
DP-9L4989	WEIGHT	37.08
DP-9L6509	CARRIER ASSEMBLY	164.86
DP-9L6863	TRANSFER PUMP 3306	87.77
DP-9L6884	NOZZLE DIRECT FEED	57.44
DP-9L6893	BONNET	19.62
DP-9L6969	PENCIL NOZZLE	58.22
DP-9L7883	USE DP-9N2366	
DP-9L9424	SPRING	0.72
DP-9M0444	PUMP, FUEL	98.65
DP-9N0194	USE DP-3T8705	
DP-9N2366	PENCIL NOZZLE	59.99
DP-9N2845	NOZZLE	14.38
DP-9N3246	D/F NOZZLE	75.55
DP-9N3299	PENCIL NOZZLE	70.99
DP-9N3979	USE DP-1W5829	
DP-9N5862	SPRING	3.56
DP-9N6173	NOZZLE	14.38
DP-9S4182	LOCK SCREW	2.44
DP-9X2519	FUEL PUMP GASKET KIT 3306B	61.34
DP-9X6388	FUEL PUMP GASKET KIT 3208	33.08
DP-9Y4966	VALVE ASSEMBLY RELIEF	4.54

OVERHAUL KIT FOR 3208 CAT* ENGINES

DPA3208-OH	OVERHAUL KIT	78.75
DPA3208-OHS	OVERHAUL KIT, SUPER	84.49
DPA3208-PM	PUMP MOUNTING KIT	16.03

>ALL PRICES ARE SUBJECT TO CHANGE WITHOUT PRIOR NOTICE.
>ALL PRICES ARE IN U.S. DOLLARS.

*All manufacturers names, numbers, symbols and descriptions are used for reference purpose only and do not imply that any part listed is the product of these manufacturers.